



NOTES:

- 1) INSTALL ANODE A MINIMUM OF 10 FEET (HORIZONTAL) FROM PIPELINE OUT OF TRAFFIC PATH.
- 2) BACKFILL ANODES WITH NATIVE MATERIAL PER MANUFACTURERS INSTRUCTIONS.
- 3) LAY PLASTIC WARNING TAPE 6" OVER CABLES FOR ALL HORIZONTAL RUNS.
- 4) PROVIDE SUFFICIENT SLACK IN CABLES TO ALLOW REMOVAL OF TERMINAL BOX FROM VALVE BOX. A MIN. OF 24" ABOVE TOP OF BOX.
- 5) FOR NON-PAVED AREAS, SEE NOTE 1 NMWD STD. No. 2.

PARTS LIST:

1	CONCRETE VALVE BOX, CHRISTY G5 W/GRADE RING
2	CAST IRON TRAFFIC COVER, CHRISTY G05CT, MARKED "WATER".
3	TERMINAL BOX, COTT, "LITTLE FINK" (FOR MULTIPLE ANODES AND CASING APPLICATIONS USE "BIG FINK")
4	ANODE
5	CONNECTOR
6	CABLE FOR DIRECT BURIAL NO. 8 AWG HMWPE COPPER WIRE.



SACRIFICIAL ANODE INSTALLATION

APPROVED <i>R. [Signature]</i>	DATE 09/05/19	REV 3	STD NO 12
-----------------------------------	------------------	----------	--------------