



NOTES:

- 1) SEAL CONDUIT ENDS AGAINST MOISTURE ENTRY WITH EXPANSIVE FOAM.
- 2) INSTALL PULL BOX EVERY 500 FEET AND AT ALL ABRUPT DIRECTION CHANGES, NOT TO EXCEED 360° TOTAL BENDS PER NEC.
- 3) FOR TRENCH SECTION REFER TO NMWD STD.1
- 4) INSTALL 1/2" MULE TAPE # WP1250P OR EQUIVALENT.

PARTS LIST:

5	CHRISTY B30 W/FLD30 LID
4	TELEMETRY CABLE, SIX PAIR, PE-18 AWG SOLID COPPER
3	2" PVC SCH40 CONDUIT
2	2" PVC SCH40 CONDUIT LONG RADIUS BEND (90°)
1	SPLICING KIT, SCOTCH CAST 78-R1 OR EQUAL.



TELEMETRY CABLE CONDUIT AND PULL BOX

APPROVED	DATE	REV	STD NO
<i>[Signature]</i>	2/5/14	2	13